

MA-6070

Digital Audio Processing B Series

YOUR DSP

Dear Customer,

Congratulations on purchasing our GoldenAcoustics mobile system product for your sound system.

This product has been designed and manufactured to GoldenAcoustics's exacting standards to ensure many years of audio enjoyment. For the best performance, we recommend that you have your GoldenAcoustics product installed by an authorized GoldenAcoustics dealer.

If you would like to install this product on your own, we recommend for you to go through this manual to familiarize yourself with all the installation requirements and procedures.


If you encounter any issues or if you have any questions on the operation of this product, please contact your nearest authorized GoldenAcoustics dealer for assistance, or you may also contact us through our website or social media channels.

WHAT'S IN THE BOX

Check the list in your gift box:

1. User's manual ×1
2. Ma-6070 ×1
3. Backup fuse ×1
4. A set of brackets and screws for mounting

Device Connections



- (1) Machine start mode switch
- (2) Power display lamp
- (3) FUSE (15A)
- (4) High level and power interface
- (5) Low-level input interface
- (6) Low-level output interface
- (7) 4-Pin power plug
- (8) USB 2.0 interface

SPECIFICATIONS

POWER DC: 9-16V

Max Power: 70Wx6



Signal Noise:100dB

EQ/Delay:31band/15ms


Frequency response:20Hz~20KHz


Dimensions: 185*146*53mm

DIMENSIONS MA-6070



Controlling the MA-6070





(1) Main menu editing area

Can be loaded and saved as computer scene files, load and save scene files of the whole machine; switch between Chinese and English, firmware update, about (check version number) and restore factory settings, etc..

(2) Filter editing area

Type of high-pass and low-pass filters, adjustable filter type, frequency and slope.

(3)Curves display area

Here all curves of output channels can be selected to be displayed

(4)Equalizer setting

Functions about EQ and a simple input source setting, as well as delay selection.

(5)Output channel

The volume, mute and phase settings of the output channel; channel alias setting for active crossover, and delay value (time or distance) input text field for you to align the speakers or set the position of sound field.

SUBSCRIBE FOR MORE INFO



Wechat
Public Account



Wechat
Channels



DouYin
Channels

WWW.HUISHENGAUDIO.COM

Copyright © 2026 GOLDEN ACOUSTICS All Rights Reserved.